

ABS Application Chart

GM ABS Vehicle Applications

Buick			
Century	1997-2005	LaCrosse	2005-2011
Enclave	2008-2011	LeSabre	1999-2005
Lucerne	2006-2011	Rainier	2004-2007
Park Avenue	1997-2005	Regal	1997-2004,2011
Rendezvous	2002-2007	Terraza	2005-2007
Cadillac			
CTS	2003-2010	Eldorado	1997-2002
DeVille	1997-2005	Escalade	2002-2011
DTS	2006-2011	Seville	1997-2004
SRX	2004-2011	XLR	2004-2009
STS	2005-2011		
Chevrolet			
Astro Van	1999-2005	Aveo	2004-2011
Avalanche	2002-2011	Blazer	1998-2005
C 1500	1999-2003	Cavalier	2000-2005
C 2500	1999-2003	Camaro	1999-2002,2010-2011
C 3500	1999, 2001-2003	Cruze	2011
Classic	2004-2005	Equinox	2005-2011
Cobalt	2005-2010	Express 1500	2003-2011
Colorado	2004-2011	Express 2500	2003-2011
Corvette	1997-2011	Express 3500	2004-2011
HHR	2006-2011	Express 4500	2009-2011
Impala	2000-2011	K 1500	1999-2003
Prizm	1998-2002	K 2500	2000-2003
S10	1998-2004	K 3500	2001-2003
Silverado 1500	2004-2007	Malibu	1997-2011
Silverado 2500	2004-2007	Monte Carlo	2000-2007
Silverado 3500	2004-2007	Silverado SS	2003-2008
Silverado Classic 1500	2007-2011	SSR	2003-2006
Silverado Classic 2500	2007-2011	Suburban	1999-2011
Silverado Classic 3500	2007-2011	Tahoe	2000-2011
Venture	2000-2005	Tracker	1999-2004
Uplander	2005-2008	TrailBlazer	2002-2009
		Traverse	2009-2011
GMC			
Acadia	2007-2011	Envoy	1998-2000,2002-2009
C 1500	1999-2003	Jimmy	1998-2002
C 2500	1999-2003	Savana 1500	2000-2011
C 3500	2001-2003	Savana 2500	1998-2011
Canyon	2004-2011	Savana 3500	2000-2011
K 1500	1999-2003	Sierra 1500	2004-2011
K 2500	2000-2003	Sierra 2500	2004-2011
K 3500	2001-2003	Sierra 3500	2004-2011
Safari	2000-2005	Savana 4500	2009-2011
Sierra Classic	2007	Sonoma	1998-2004
Sierra Denali	2003-2011	Terrain	2010-2011
Yukon	2000-2011	Yukon XL /Denali	2001-2011
Hummer			

H2	2003-2009	H3	2006-2010
Oldsmobile			
Alero	1999-2004	Cutlass	1997-1999
Aurora	2001-2003	Intrigue	1998-2002
Bravada	1996-2004	Silhouette	2000-2004
Pontiac			
Aztek	2001-2005	G6	2005-2010
Bonneville	2000-2005	G8	2008-2009
Firebird	1999-2002	Grand AM	1999-2005
G3	2009	Grand Prix	2004-2008
G5	2007-2009	GTO	2006
Montana	2000-2005	Sunfire	2000-2005
Montana SV6	2005-2007	Torrent	2006-2009
Solstice	2006-2009	Vibe	2003-2008
Chrysler ABS Vehicle Applications			
Chrysler			
300	2005-2009	Crossfire (excludes SRT-6)	2008
300 SRT-8	2007-2009	LHS	1998-2001
300m	1999-2004	Pacifica	2004-2006
Aspen	2007-2009	PT Cruiser	2001-2009
Concorde	1998-2004	Sebring	2001-2010
Voyager	2001-2003	Town & Country	2001-2009
Dodge			
Avenger	2008-2009	Caravan	2001-2004, 2006-2007
Caliber	2007	Charger	2006-2009
Caliber SRT-4	2007	Charger SRT-8	2006-2009
Dakota	2001-2009	Grand Caravan	2001-2002,2004-2009
Durango	2001-2009	Intrepid	1998-2004
Magnum	2005-2008	Journey	2009
Magnum SRT-8	2006-2007	Nitro	2007-2009
Neon	2000-2005	Ram 1500	2003-2009
SRT-4	2003-2005	Ram 2500	2003-2009
Ram SRT-10	2004-2006	Ram 3500	2003-2009
Sprinter 2500	2007	Stratus Sedan	2001-2006
Sprinter 3500	2007	Viper	2001-2002
Jeep			
Commander	2006-2009	Grand Cherokee SRT-8	2006,2008-2009
Compass	2007-2009	Liberty	2002-2011
Grand Cherokee	1999-2009	Patriot	2007
Wrangler	2004-2009		
Ford ABS Vehicle Applications			
Ford			
Contour	1996-2000	Edge	2007-2010
Crown Victoria	1996-2010	Escape	2001-2010
E-150 (Excludes DIESEL Engines)	1997-2010	Escort	1997-2003
E-250 (Excludes DIESEL Engines)	1997-2010	Excursion (Excludes DIESEL Engines)	2000-2005
E-350 (Excludes DIESEL Engines)	1997-2010	Expedition	1997-2010
E-450 (Excludes DIESEL Engines)	2008-2010	Explorer	1996-2010
F-150 (Excludes 1998 w/Vin Z)	1997-2010	Explorer Sport Trac	2001-2005,2007-2010

F-250 (Excludes DIESEL Engines)	1997-2010	Five Hundred	2005-2007
F-350 (Excludes DIESEL Engines)	1999-2010	Flex	2009-2010
F-450 (Excludes DIESEL Engines)	2008-2010	Focus	2000-2010
F-550 (Excludes DIESEL Engines)	2008-2010	Freestar	2004-2007
Fusion	2006-2010	Taurus X	2008-2009
Mustang	1996-2010	Thunderbird	1996,2002-2005
Ranger	1996-2010	Transit Connect	2010
Taurus	1996-2010	Windstar	1996-2003
Lincoln			
Aviator	2003-2005	LS	2002-2006
Blackwood	2002	Mark LT	2006-2008
Continental	1996-2002	Mark VIII	1997-1998
MKS	2009-2010	Navigator	1998-2010
MKT	2010	Town Car	1998-2010
MKX	2007-2010	Zephyr	2006
MKZ	2007-2010		
Mercury			
Cougar	1999-2002	Mariner	2005-2010
Grand Marquis	1996-2010	Milan	2006-2010
Marauder	2003-2004	Montego	2005-2007
Mountaineer	1997-2010	Sable	1996-2005,2008-2009
Mystique	1996-2000	Tracer	1997-1999
Toyota ABS Vehicle Applications			
Lexus			
ES 330	2004-2006	ES 300	1999-2000,2002-2003
ES 350	2007-2011	GS 400	1998-2000
GS 300	1998-2006	GS 430	2001-2007
GS 350	2007-2011	GX 470	2003-2009
IS 250	2006-2008	IS F	2008-2009
IS 300	2001-2005	LS 400	1998-2000
IS 350	2006-2009	LS 430	2001-2006
LS 460	2007-2011	RX 300	2001-2003
LS 600h	2008-2010	RX 330	2004-2006
LX 470	1998-2007	RX 350	2007-2011
LX 570	2008-2011	SC 300	1999-2000
SC 400	1999-2000	SC 430	2002-2010
Scion			
tC	2005-2010	xB	2004-2006,2009-2010
xA	2004-2006		
Toyota			
4-Runner	2001-2011	Camry Solara	2000,2004-2008
Avalon	2002-2011	Celica	2000-2005
Camry	2000-2011	Corolla	2000-2008
Echo	2000-2001	Land Cruiser	2000-2010
FJ Cruiser	2007-2011	Matrix	2003-2011
Highlander (Excludes Hybrid Models)	2001-2011	MR2 Spyder	2000-2005
Sienna	2001-2010	Prius	2001-2009
Tacoma	2003-2010	Rav4	2001,2003-2011
Tundra	2000-2010	Sequoia	2001-2011
Yaris	2007		

Honda ABS Vehicle Applications

Acura			
Integra	1998-2001	CL	1998-1999,2001-2003
MDX	2001-2009	RDX	2007-2009
NSX	2000-2004	RL	1998-2009
RSX	2002-2006	TL	1997-2009
SLX	1996-1999	TSX	2004-2009
Honda			
Accord	1998-2009	Element	2003-2008
Civic	1996-2009	Fit	2007-2009
CR-V	1997-2009	Insight	2000-2005
Odyssey	1998-2009	Ridgeline	2007-2008
Pilot	2003-2009	S2000	2000-2009
Prelude	1997-2001		